

OPERATING AND SERVICE MANUAL

12924A

CARD READER INTERFACE KIT

(FOR 2100, 2114, 2115, AND 2116 COMPUTERS)

Printed-Circuit Assembly:

12924-60001, Series 1212

Note

This manual should be retained with the applicable computer documentation.

TABLE OF CONTENTS

Section	Page
I GENERAL INFORMATION	
1-1. Introduction	1-1
1-3. General Description	1-1
1-7. Identification	1-1
1-9. Specifications	1-1
II INSTALLATION AND PROGRAMMING	
2-1. Introduction	2-1
2-3. Unpacking and Inspection	2-1
2-5. Installation	2-1
2-7. Reshipment	2-1
2-11. Programming	2-1
2-13. Card Reader Characteristics	2-1
2-15. Status Signals	2-2
2-19. Timing	2-2
2-24. Non-Interrupt	2-5
2-25. Interrupt	2-5
2-26. Direct Memory Access	2-5
III THEORY OF OPERATION	
3-1. Introduction	3-1
3-3. Functional Description	3-1
3-9. Detailed Circuit Description	3-1
3-11. Turn-On and Preset Circuit	3-2
3-14. Select Code Detector Circuit	3-2
3-16. Interrupt Circuit	3-2
3-20. Pick Command Circuit	3-3
3-25. End-Of-Operation Circuit	3-3
3-29. Status/Data Circuit	3-4
3-32. Lost Data Circuit	3-4
3-34. Status Signal Circuits	3-4
IV MAINTENANCE	
4-1. Introduction	4-1
4-3. Preventive Maintenance	4-1
4-5. Diagnostics	4-1
4-7. Troubleshooting	4-1
4-9. Cable Assembly Connector Pin Functions	4-1
V REPLACEABLE PARTS	
5-1. Introduction	5-1
5-4. Ordering Information	5-1

LIST OF ILLUSTRATIONS

Figure	Title	Page
1-1.	HP 12924A Card Reader Interface Kit	1-1
2-1.	Card Reader Interface Timing Diagram	2-4
3-1.	Card Reader Interface Signal Flow, Block Diagram	3-2
3-2.	Card Reader and Interface PCA Status Signals	3-5
3-3.	Operational Flow Diagram	3-7
4-1.	Card Reader Interface PCA Parts Location and Logic Diagrams	4-3
4-2.	Integrated Circuit Diagrams	4-5

LIST OF TABLES

Table	Title	Page
1-1.	Interface Kit Specifications	1-2
2-1.	Card Reader Status Signals	2-3
4-1.	Cable Assembly Connector Pin Assignments	4-1
4-2.	Card Reader Interface PCA, Replaceable Parts	4-2
4-3.	Integrated Circuit Characteristics	4-5
5-1.	Card Reader Interface Kit Replaceable Parts	5-2
5-2.	Code List of Manufacturers	5-2
5-3.	Reference Designations and Abbreviations	5-3

1-1. INTRODUCTION.

1-2. This operating and service manual covers general information, installation, programming, theory of operation, maintenance, and replaceable parts for the HP 12924A Card Reader Interface Kit (figure 1-1).

1-3. GENERAL DESCRIPTION.

1-4. The HP 12924A Card Reader Interface Kit provides the necessary equipment to enable using the HP 2892A Card Reader with an HP 2100, 2114, 2115, or 2116 Computer. The kit contains the following items:

- a. Card reader interface printed-circuit assembly (PCA), part no. 12924-60001.
- b. Cable assembly, part no. 12924-60002.
- c. *Operating and Service Manual*, part no. 12924-90001.

1-5. The card reader interface kit uses a printed-circuit assembly with integrated circuits to transfer data and status information between the card reader and the computer. In addition, the interface PCA contains control and interrupt logic circuits that permit programming of the card reader operations using the I/O interrupt or the direct memory access (DMA) method.


1-6. Twelve parallel bits of data are transferred to the computer. Twelve bits of status information are available to monitor operation of the card reader. The first 10 bits are transferred through a 12-bit register on the interface PCA and the remaining two bits are transferred through two separate gate circuits on the PCA.

1-7. IDENTIFICATION.

1-8. Printed-circuit assembly revisions are identified by a revision letter, a series code, and a division code stamped on the board (e.g., A-1024-22). The revision letter identifies the version of the etched trace pattern on the unloaded PCA. The series code (four middle digits) refers to the electrical characteristics of the loaded PCA and the positions of the components. The division code (last two digits) identifies the Hewlett-Packard division that manufactured the PCA. If the series code stamped on the printed-circuit assembly does not agree with the series code shown on the title page of this manual, there are differences between your PCA and the PCA described in this manual. These differences are described in manual supplements available at the nearest HP Sales and Service Office. (Sales and Service Offices are listed at the back of this manual.)

1-9. SPECIFICATIONS.

1-10. Specifications for the card reader interface kit are given in table 1-1.



2210-1

Figure 1-1. HP 12924A Card Reader Interface Kit

Table 1-1. Interface Kit Specifications

CHARACTERISTICS	SPECIFICATIONS
CURRENT REQUIRED FROM COMPUTER:	
+4.85 Volt Supply:	0.970 ampere
- 2 Volt Supply:	0.43 ampere
DATA TRANSFER:	
Media:	80-column tabular cards per Electronic Industries Standard RS-292.
Rate:	600 cards per minute \pm 10 percent.
Code:	Hollerith (12 bits parallel per column, 1 column per character).
LOGIC VOLTAGE LEVELS:	
To and from Computer:	
Logic 1:	+2.4 volts dc (minimum)
Logic 0:	+0.4 volts dc (maximum)
To Card Reader:	
POPIO Signal:	
Logic 1:	+0.4 volts dc (maximum)
Logic 0:	+2.4 volts dc (minimum)
Pick Command Signal:	
Logic 1:	+0.7 volts dc (maximum)
Logic 0:	+4.0 volts dc (minimum)
From Card Reader:	
Logic 1:	+0.25 volts dc (maximum)
Logic 0:	+4.5 volts dc (minimum)

INSTALLATION AND PROGRAMMING

2-1. INTRODUCTION.

2-2. This section provides information on unpacking, inspection, installation, reshipment, and programming for the HP 12924A Card Reader Interface Kit.

2-3. UNPACKING AND INSPECTION.

2-4. If the shipping carton is damaged upon receipt, request that the carrier's agent be present when the kit is unpacked. Inspect the kit for damage (cracks, broken parts, etc.). If the kit is damaged and fails to meet specifications, notify the carrier and the nearest Hewlett-Packard Sales and Service Office immediately. (Sales and Service Offices are listed at the back of this manual.) Retain the shipping container and the packing material for the carrier's inspection. The Hewlett-Packard Sales and Service Office will arrange for the repair or replacement of the damaged kit without waiting for any claims against the carrier to be settled.

2-5. INSTALLATION.

2-6. Install the interface PCA and cable assembly as follows:

- a. Determine if the computer power supplies will provide the additional current required for operation of the interface PCA. Refer to the Hewlett-Packard computer documentation for a listing of current available from the computer power supplies.
- b. Turn off computer and card reader power.

CAUTION

Computer power must be off before installing the interface kit, or damage to the computer may result.

- c. Open computer for access to I/O PCA slots.

Note: The card reader requires a high priority I/O slot in the computer. In most systems, devices with a data transfer rate of 1000 16-bit words per second or faster are the only devices that should be placed in a higher priority slot.

- d. Plug interface PCA into the I/O slot assigned for the particular computer system. Make certain that all higher priority slots have either another I/O PCA or a priority jumper PCA installed.

- e. Pass the interface PCA connector of the cable assembly through opening at rear of computer. Slide connector onto interface PCA and close computer.
- f. Connect other end of cable assembly to the mating connector at the rear of the card reader.
- g. Run diagnostic test as described in the Diagnostic Program Procedure, part number 02892-90006, contained in the *Manual of Diagnostics* to verify that the interface PCA is functioning properly.

2-7. RESHIPMENT.

2-8. If an item of the kit is to be shipped to Hewlett-Packard for service or repair, attach a tag to the item identifying the owner and indicating the service or repair to be accomplished. Include the accessory number of the kit.

2-9. Package the item in the original factory packaging material, if available. If the original material is not available, standard factory packaging material can be obtained from a local Hewlett-Packard Sales and Service Office.

2-10. If standard factory packaging material is not used, wrap the item in Air Cap TH-240 Cushioning (or equivalent) manufactured by Sealed Air Corp., Hawthorne, N.J., and place in a corrugated carton (200 pound test material). Seal the shipping carton securely and mark it "FRAGILE" to ensure careful handling.

Note: In any correspondence, identify the kit by accessory number. Refer any questions to the nearest Hewlett-Packard Sales and Service Office.

2-11. PROGRAMMING.

2-12. The following paragraphs provide information for programming the card reader interface PCA and card reader. This information consists of the card reader characteristics, and status and timing considerations. Additional programming information is available in the software manuals provided with the computer.

2-13. CARD READER CHARACTERISTICS.

2-14. The card reader reads up to 600 punched cards per minute at 60 Hz or 50 Hz. Each card contains 80 columns of data. Columns are arranged in 12 rows to represent a 12-bit Hollerith-coded character. Card reading is enabled by a "not" Pick Command signal from the computer and

continues as long as cards are in the hopper and the command is available. A card reading sequence starts when a card is picked from the input hopper and committed to the read station. The card then moves through the read station without stopping, and all 80 Hollerith-coded characters are read out at a constant rate. These characters are transferred from the card reader data storage register to the interface card one column at a time. An automatic stop occurs if a device error is detected in the card reader operation. The cause of the error is displayed on the card reader control panel and relayed to the computer for program control through the status circuitry. To continue operation after an error indication, press the card reader RESET switch after the cause of the error has been corrected.

2-15. STATUS SIGNALS.

2-16. The card reader supplies eight status signals that are sent to the interface PCA. In addition, five status signals are developed by the interface PCA. These signals appear as bits 0 through 3, 5 through 9, 11, 12, and 15 of each status word transferred from the interface PAC to the computer (bits 4, 10, 13, and 14 are unused). To determine the card reader status, the signals for bits 0 through 3, 5 through 9, and 11 of the status word are first loaded into the interface PCA data register. Then, the full 14-bit (bits 0 through 11, 12, and 15) word is transferred to the computer register by an LIA or LIB instruction and the card reader select code. The signals for bits 12 and 15 are transferred through the interface PCA output gates whenever a load instruction is programmed with a card reader select code. Bits 0 through 11 are loaded into the interface PCA data register by one of the following four methods:

- a. An OTA, or OTB instruction (I/O output instruction) is programmed with the card reader select code.
- b. An end-of-operation (EOP) interrupt occurs.
- c. Computer power turn-on or preset occurs.

2-17. Bits 0 through 11 of the status word remain loaded in the interface PCA data register until one of the following three conditions occur:

- a. The status word is replaced with a new status word by one of the four methods listed in paragraph 2-16.
- b. The next card is picked to pass through the card reader read station.
- c. An LIA/LIB or MIA/MIB instruction is programmed with the card reader select code to transfer the status information to the computer. This allows the next data word to replace the status word in the interface PCA register when a "not" Index Mark signal is received from the card reader.

2-18. Table 2-1 lists the status signals by name and bit position, and also lists the logic indications at the interface PCA output pins.

2-19. TIMING.

2-20. Card reader operation is synchronized through "not" Pick Command and "not" Index Mark signals. These signals, and all other signals routed between the card reader and the interface PCA, are ground-true at the card reader. The "not" Pick Command signal is initiated on the interface PCA and sent to the card reader when the computer is ready to accept data. This is done for each card to be read. If the card reader is on-line and ready to read cards, it responds to the "not" Pick Command signal by starting a card through the card reader read station. Once a card is started (picked), it continues through the read station at a constant speed. As the card passes through the read station, the reader generates a "not" Index Mark signal. The "not" Index Mark signal is a pulse that occurs as each data column of the card passes through the read station. Therefore, each card causes 80 "not" Index Mark signals to be generated. These pulses are sent to the interface PCA to synchronize the transfer of each data column from the card reader with the interface PCA signals.

2-21. Figure 2-1 is a timing diagram showing the timing of a card reading sequence. A card reading sequence is initiated by a Set Control, Clear Flag (STC,C) instruction. If the card reader is on-line and ready to read, the STC portion of the instruction causes the "not" Pick Command signal to go low and also causes the Data signal from the Status/Data FF to go high. When the first card column enters the read station, the "not" Index Mark signal is sent to the interface PCA, causing the "not" Pick Command signal to go high. The "not" Pick signal then remains high until the next STC instruction. The "not" Index Mark signal is gated with the Data signal to enable the interface PCA data register. An input signal from each data row on the punched card is also gated with the Data signal. These gated inputs are then loaded into the enabled register. The "not" Index Mark signal strobes each data column successively into the interface PCA data register.

2-22. To transfer a column of data from the interface PCA data register to the computer, a load instruction such as LIA, LIB, MIA, or MIB (I/O input instruction) is required. The load instruction generates the IOI signal that is sent to the interface PCA. This IOI signal enables the interface PCA output gates so that data is transferred through the gates to the computer. To prevent loss of data, each column of data must be transferred to the computer before the next column of data is loaded into the interface PCA data register.


2-23. The "not" Index Mark signal also causes the Flag signal to go high and the IOI signal causes the Flag signal to go low. The high Flag signal initiates a Request for Service (SRQ) signal and also enables the interface PCA interrupt circuits. If conditions are met for the computer to accept data from the card reader, the computer enables the data transfer and causes the Flag signal to go low. Three methods are available to meet the computer requirements for data transfer. The three methods are discussed in the following paragraphs.

Table 2-1. Card Reader Status Signals

BIT	STATUS SIGNAL	LOGIC
0	"not" Ready or Off-Line or Busy	<p>Logic 1 indicates card reader is on-line and is ready to send data.</p> <p>Logic 0 indicates card reader is not on-line or not ready to send data.</p>
1	Trouble During Read	<p>Logic 1 indicates that one or more of the following troubles occurred:</p> <ul style="list-style-type: none"> a. Card motion error. b. Light/Dark error. c. Data loss. <p>Logic 0 indicates that no trouble indication occurred.</p>
2	Off-Line	<p>Logic 1 indicates that the card reader is operating in the off-line mode.</p> <p>Logic 0 indicates that the card reader is not operating in the off-line mode.</p>
3	Data Lost	<p>Logic 1 indicates that data was lost due to one of the following conditions:</p> <ul style="list-style-type: none"> a. A data word was loaded into the interface PCA register by an STC instruction but was not transferred to the computer by an LIA or LIB instruction before the next "not" Data Strobe signal was received from the card reader. b. A data word was contained in the interface PCA register when the EOP signal went high or an OTA or OTB instruction was issued. c. A status word was loaded into the interface PCA register by an OTA or OTB instruction but was not transferred to the computer by an LIA or LIB instruction before the next "not" Data Strobe signal was received from the card reader. <p>Logic 0 indicates that no data was lost due to a timing error.</p>
4	Not used	
5	Hopper Empty or Stacker Full	<p>Logic 1 indicates that the card reader hopper is empty or the stacker is full.</p> <p>Logic 0 indicates that the hopper is not empty and the stacker is not full.</p>
6	Stacker Full	<p>Logic 1 indicates that the card reader stacker is full.</p> <p>Logic 0 indicates that the stacker will accept cards.</p>
7	End-of-File and Hopper Empty	<p>Logic 1 indicates that the card reader End-of-File signal was high and the hopper is empty.</p> <p>Logic 0 indicates that the End-of-File signal was low or there is a card in the hopper.</p>
8	Pick	<p>Logic 1 indicates that the card reader is not in the off-line mode, the first data column has not been read, and an STC instruction was issued with the card reader select code.</p> <p>Logic 0 indicates that one of the following condition has occurred:</p> <ul style="list-style-type: none"> a. Card reader sent "not" Index Mark signal to interface PCA. b. An EOP interrupt occurred. c. Card reader was in off-line mode. d. Computer power turn-on or preset occurred. e. A CLC instruction was issued with the card reader select code.
9	"not" Error (L/D)	<p>Logic 1 indicates the card reader detected a leading edge dark check or trailing edge dark check or light check.</p> <p>Logic 0 indicates that all read station photocells were functioning before and after a card was read.</p>
10	Not used	
11	Motion/Pick Check	<p>Logic 1 indicates that the last card failed to move from the card reader read station to the stacker station or was not picked from the input hopper.</p> <p>Logic 0 indicates normal card motion.</p>

Table 2-1. Card Reader Status Signals (Continued)

BIT	STATUS SIGNAL	LOGIC
12	"not" Read In Progress	Logic 1 indicates that computer power turn-on, computer preset, or an EOP interrupt has occurred. Logic 0 indicates the card reader was on-line and ready and the Pick signal went high.
13	Not used	
14	Not used	
15	End of Operation	Logic 1 indicates that one of the following conditions has occurred: a. Computer power turn-on or preset. b. Pick signal was high when reader was switched to off-line mode. c. Card reader was on-line and ready but Pick signal did not go high. d. Card reader went to ready mode at end of card reading sequence. Status is now contained in data-register. e. Card reader failed to read a card within 875 ± 150 milliseconds after the Pick signal went high. Logic 0 indicates that no end-of-operation (EOP) interrupt has occurred.



2210-2

Figure 2-1. Card Reader Interface Timing Diagram

2-24. **NON-INTERRUPT.** The non-interrupt method is the simplest method of programming the card reader. With this method the computer is held in a program loop by a skip flag instruction until all 80 columns of data have been transferred to the computer memory. Thus, the computer central processor is caused to wait a few milliseconds (normally 1.25 milliseconds) between each transfer of data while the card reader is getting the data ready for transfer. This is the most inefficient method of data transfer and computer time utilization.

2-25. **INTERRUPT.** The interrupt method allows the computer to service other I/O devices on a priority basis

between each card column data transfer. This provides more efficient use of computer time but may cause data to be lost if the computer fails to service each column of data at the proper time.

2-26. **DIRECT MEMORY ACCESS.** Direct memory access (DMA) provides increased speed in handling the transfer of data from the card reader to the computer. When transferring data under DMA control, the computer central processor operation is frozen, the 80 columns of data are transferred directly to the computer memory, then the computer central processor resumes operation as though no interruption had occurred. This is the most efficient method of data transfer for high speed devices.

3-1. INTRODUCTION.

3-2. This section contains a functional description and a detailed circuit description of the card reader interface PCA. Also included at the back of this section is an operational flow diagram (figure 3-3) of the interface PCA.

3-3. FUNCTIONAL DESCRIPTION.

3-4. The card reader interface PCA contains a 12-bit data register and the necessary control circuitry to transfer data and status information from the card reader to the computer. All functions of the interface PCA are performed under the control of programmed instructions and result in data being read from punched cards and stored in the computer. (See figure 3-1.) Initial operating conditions for the interface PCA are established when the POPIO signal and CRS signal are received from the computer. The POPIO signal is generated by the computer when power is turned on. The CRS signal is generated by the computer when the PRESET switch is pressed. The POPIO signal is also inverted and sent to the card reader as the "not" EOF Clear signal to clear the End-of-File FF.

3-5. Programmed instructions initiate the control signals that are sent from the computer to the interface PCA, controlling the card reader and the data transferring process. If the status signals from the card reader indicate that the card reader is on-line, ready to read cards, and not in the process of reading a card, the control signals from the computer cause the interface PCA to generate a "not" Pick Command signal. This signal causes the card reader to pick the bottom card from the input hopper and start it through the read station. Once a card is started along the read path, it automatically continues through the read station to the output stacker without interruption. If a malfunction has occurred during the card's progress through the read path, it will be sensed by the error circuitry of the card reader causing the card reader to halt after the card is in the output stacker. The error condition is sent to the interface PCA and will be registered in the next status word sent to the computer. A "not" Pick Command signal is required to pick each card and start it through the read station. A status word is sent to the computer by the card reader interface after each card is read.

3-6. Data is read from each punched card as the card passes through the read station. On the punched cards, data is arranged in 80 columns and 12 rows. Each column of 12 rows represents one character (computer word) and each row represents one bit of the character. As each column of data enters the read station, the 12 data bits are stored in the card reader character buffer the outputs of which are impressed on the interface PCA data input lines. When the

character buffer output lines have become stable, the card reader generates a "not" Index Mark signal that is sent to the interface PCA. The "not" Index Mark signal enables the interface PCA data register, causing the 12 data bits to be loaded into the data register. This 12-bit data word is then transferred from the interface PCA data register to the computer before the next data word is ready to be loaded into the interface PCA data register.


3-7. A low "not" Index Mark signal also results in a Skip on Flag (SKF), Interrupt Request (IRQ), or Service Request (SRQ) signal, depending upon the programmed method of transferring data from the interface PCA to the computer. Any one of these signals condition the computer for data transfer. To complete the data transfer, a load instruction such as LIA, LIB, MIA or MIB (I/O input instruction) must be programmed for each data word (80 per card). When these instructions are used with normal software driver programs, each 12-bit character is converted to an equivalent 8-bit ASCII coded character. Two eight-bit characters can then be placed in one computer location. This process is referred to as character packing.

3-8. Operation of the card reader is monitored by eight "not" status signals (Busy, Off-Line, Ready, Hopper Empty, Stacker Full, End-of-File, Error L/D, and Motion/Pick Check) that are routed to the interface PCA. Five additional status signals ("not" Read-in-Progress, Lost Data, Pick, End-of-Operation, and Trouble During Read) are developed on the interface PCA to monitor the interface PCA operation. Eleven of these signals are routed to the status input gates of the interface PCA data register. When the status input gates are enabled by an OTA or OTB instruction (I/O output instruction), the status signals are loaded into the data register and the data inputs are inhibited until the status word is transferred to the computer. Status information is transferred from the interface PCA to the computer by an I/O input instruction. Two status bits, bits 12 and 15, are not routed through the data register but are transferred to the computer whenever an I/O input instruction is processed (during data or status transfers).

3-9. DETAILED CIRCUIT DESCRIPTION.

3-10. The card reader interface PCA uses integrated circuits with positive-true logic. A logic diagram and parts location diagram for the interface PCA are provided in figure 4-1. Individual diagrams for the integrated circuits are provided in figure 4-2. To describe operation of the interface PCA circuits, the circuits are divided into the following functional groups:

a. Turn-On and Preset.



2210-3

Figure 3-1. Card Reader Interface Signal Flow, Block Diagram

- b. Select Code Detector.
- c. Pick Command.
- d. End-of-Operation
- e. Status/Data.
- f. Lost Data.
- g. Status Signal.
- h. Data Register. (Refer to paragraphs 3-13 and 3-25 through 3-27.)

3-11. TURN-ON AND PRESET CIRCUIT.

3-12. The turn-on and preset circuit establishes the initial conditions for the interface PCA logic circuits and clears the End-of-File FF in the card reader. When the computer power is turned on or when the computer PRESET switch is pressed, the computer sends POPIO and CRS signals to the interface PCA. The POPIO signal sets the Flag Buffer FF, which enables the Flag FF and causes it to be set at the next I/O time T2 with the ENF signal. Also, the POPIO signal is inverted by gate U73A and routed to the card reader as the "not" EOF Clear signal where it clears the End-of-File FF. The End-of-File FF generates the status signal ("not" EOF) which is routed back to the interface PCA.

3-13. The CRS signal causes the data register to be cleared and initiates a status check by first clearing the Control, Pick, Read-In-Progress, Lost Data, and Data-In-Register FFs, and then setting the EOP and Status/Data FFs. When the Status/Data FF sets, status bits 0 through 11 are gated to the data register set inputs. The CRS signal is then routed through gates U12A and U12B to the clock inputs of the register. This enables the data register and loads it with the current status information. If the status word is subsequently transferred to computer memory by an I/O input instruction, status bits 12 and 15 must be logic 1s and bit 3 must be logic 0, indicating no read is in progress, the interface is currently in the end-of-operation

status, and no data has been lost. All other bits depend upon the current status of the card reader.

3-14. SELECT CODE DETECTOR CIRCUIT.

3-15. The select code circuit enables the card reader interface PCA control circuits. When the card reader is addressed by the instruction being processed by the computer, the SCM and SCL signals become high at the interface PCA. Since any instruction referencing an external device is in the computer I/O group instruction set, the IOG signal is also high at the interface PCA. These three signals being high enable the control circuits on the interface PCA in such a way as to allow the instruction being processed to activate the necessary interface circuits, thus completing the instruction. The select code necessary to address a certain interface PCA and I/O device is determined by the physical location of the interface PCA within the I/O section of the computer.

3-16. INTERRUPT CIRCUIT.

3-17. Computer operation is interrupted by the interrupt circuit on a priority basis. During the interrupt, data is transferred to computer memory by the card reader. The interrupt circuit consists of IRQ FF (U24A and U24B) and associated circuits. Initial conditions are established when the Flag FF (U25A and U35A) and Control FF (U24C and U34B) are set and an IEN signal is received to enable gate U35B. An IEN signal is received when an STF instruction is programmed with select code 00. The low output of gate U35B is inverted and applied to gate U14A with the SIR signal (T5) from gate U26C, a signal from the Flag Buffer FF (U15A and U15B), and the PRH signal. The PRH signal indicates that there are no higher priority devices requesting an interrupt. The low output of gate U35B causes the output of gate U17B to go low, sending a low PRL signal to all lower priority device interface PCAs. The PRL signal inhibits all lower priority interface PCAs from interrupting the card reader. If all inputs to gate U14A are high, the output is low, setting the IRQ FF, providing the FLG and IRQ signals to the computer to initiate an interrupt.

3-18. At the next T2 time, the ENF signal clears the IRQ FF to allow any higher priority device to request service during the interrupt. If no higher priority device requests service the PRH signal remains high, as do the other inputs to gate U14A, and at time T5, the SIR signal sets the IRQ FF a second time. The FLG and IRQ signals are then used to indicate the interrupt address.

3-19. The computer sends an IAK signal to the interface PCA to clear the Flag Buffer FF and executes the instruction contained in memory at the interrupt address. At time T2, the ENF signal clears the IRQ FF. Clearing the Flag Buffer FF prevents the IRQ FF from being set again after the requested interrupt is enabled. The Flag FF remains set, however, to maintain the low PRL signal to lower priority devices until processing of the requested interrupt is complete. To clear the Flag FF and enable lower priority devices, a CLF instruction must be programmed.

3-20. PICK COMMAND CIRCUIT.

3-21. The pick command circuit generates the "not" Pick Command signal that starts the punched card through the card reader read station. This circuit includes the Pick and Read-In-Progress FFs and transistor Q1 and uses the "not" Index Mark, "not" Ready, and "not" Off-Line signal inputs from the card reader and the PON signal input from the computer.

3-22. The Pick FF is set by an STC instruction if the card reader is on-line but is not in the process of reading a card. (See figure 3-3.) When the card reader is in the ready condition, the Ready · "not" Off-Line · "not" Busy signal and the set side of the Pick FF combine to set the Read-In-Progress FF. The set-side outputs from the Pick and Read-In-Progress FFs are then combined at U73B to provide a ground potential at the emitter of transistor Q1. Q1 is an NPN transistor with a positive potential on its base via the PON signal which is high as long as computer power is turned on. Ground potential on the emitter and a positive potential on the base of Q1 causes Q1 to conduct so that a low "not" Pick Command signal is sent to the card reader.

3-23. The low "not" Pick Command signal causes the card reader to pick a card and start it through the read station. When the first character has been read and is in the character buffer of the card reader, the card reader sends a low (ground) "not" Index Mark signal to the interface PCA. When the "not" Index Mark signal goes low, pin 11 of gate U44C goes high and pin 10 remains high until capacitor C16 discharges. Since pin 9 of gate U44C is high when the Read-In-Progress FF is set, the "not" Index Mark signal transition from high to low causes a 300-nanosecond negative-going pulse (Strobe signal) to be generated at the output pin 8 of gate U44C. This Strobe signal is used to generate the clock input signal to the interface PCA data register and also clears the Pick FF. Clearing the Pick FF causes the "not" Pick Command signal to go high and conditions the interface PCA for the next STC instruction.

3-24. The Pick FF is also cleared if the card reader is placed in the off-line mode or if a CLC instruction is processed by the computer. Both the Pick and Read-In-Progress FFs are cleared by a CRS signal or an end-of-operation interrupt. An end-of-operation interrupt normally occurs as each card leaves the read station and the card reader becomes not busy.

3-25. END-OF-OPERATION CIRCUIT.

3-26. The end-of-operation circuit generates the End-of-Operation Interrupt (EOPI) signal and the End-of-Operation (EOP) status signal. This circuit includes the Pick Time-Out Delay one-shot, the EOP FF, and the Read-In-Progress FF, and is controlled by the pick command circuits and the "not" Busy signal from the card reader. A normal End-of-Operation Interrupt signal is generated as each card leaves the card reader read station. Gate U14B generates this normal interrupt signal as follows: A high signal is applied to U14B, pins 9 and 12, when the Pick FF is cleared by the Strobe signal. While the card is being read, a high signal is applied to U14B, pin 13. When the card leaves the read station and the card reader becomes not busy, a high signal is applied to U14B, pin 10, and the signal at pin 13 remains high until capacitor C18 discharges. This provides a 300-nanosecond negative-going pulse at output pin 8 of U14B. The negative-going pulse causes the output of U52 to go high, resulting in setting the End-of-Operation FF.

3-27. An EOPI signal is also generated by either of two malfunctions. Gate U32A causes an EOPI signal to be generated if the card reader is placed in the off-line mode when the Pick FF is set. Also, the Pick Time-Out Delay one-shot causes an EOPI signal to be generated if a normal EOPI signal does not occur within 875 ± 150 milliseconds after the Read-In-Progress FF was set. This 875-millisecond delay time is greater than the time required to read a card; therefore, the Read-In-Progress FF would normally be cleared before the delay one-shot has timed-out. Each time the Read-In-Progress FF is set, the Pick Time-Out Delay one-shot is set for the 875-millisecond time delay. If a pick fail occurs, the Read-In-Progress FF does not get cleared and the time delay expires. A high signal is then applied to U32D, pin 9. Since pin 10 of U32D is high due to the Read-In-Progress FF being set, U32D provides a low output at pin 8. The low output at pin 8 causes the EOPI signal to be generated, clearing the Read-In-Progress FF. Pin 8 of U32D remains low for 300 nanoseconds after the clearing of the Read-In-Progress FF, due to the discharging of capacitor C5 through resistor R3.

3-28. Whenever an end-of-operation interrupt occurs, the low output from U45A causes the following actions:

- a. The EOP FF is set to provide a logic 1 at IOBI 15.
- b. The Pick and Read-In-Progress FFs are cleared.
- c. The Lost Data FF is set if there was data in the register.

- d. The Status/Data FF is set to enable the status input gates to the data register.
- e. The data register clock input is enabled to load the current status word in the data register.
- f. If the Flag FF was cleared, the Flag Buffer FF is set and the Flag FF is set at the next time T2 by the ENF signal.

3-29. STATUS/DATA CIRCUIT

3-30. The status/data circuit selects either status information or data for loading into the interface PCA data register. This circuit includes the Status/Data FF and is controlled by programmed I/O instructions from the computer, the EOPI signal, and the CRS signal from the computer PRESET switch. To load status information into the data register, an I/O output instruction is processed by the computer. The computer then develops an IOO signal that is sent to the interface PCA to set the Status/Data FF, thus generating the Status signal. The Status signal gates the status information from the card reader to the input of the interface PCA data register. When the Status signal is generated, the Enable 1 and Enable 2 signals are also generated by the IOO signal. The Enable signals clock the status information into the data register. An I/O input instruction must now be processed by the computer in order to transfer the information in the data register to the computer. The EOPI signal causes the Status signal to be generated at the end of each card as the card passes through the card reader read station. Also, when the preset switch on the computer is pressed, the Status signal is generated.

3-31. The STC signal from the computer causes the Status/Data FF to generate the Data signal when a data word is to be transferred from the card reader to the interface PCA data register. At the same time the Data signal is generated, the Pick FF is set and the Data-In-Register FF is cleared as long as the card reader is not in the Off-Line mode or the Read-In-Progress FF is set. A true IOI signal is received from the computer whenever an I/O input instruction such as LIA or LIB is processed by the computer. The IOI signal enables the interface PCA output gates and applies a high signal to pin 9 of U21D. When the IOI signal subsequently goes low, pin 10 of U21D goes high and pin 9 remains high until capacitor C3 discharges. This causes a 50-nanosecond negative-going output pulse from U21D that causes the Status/Data FF to generate the Data signal that gates the data from the card reader to the input of the interface PCA data register.


3-32. LOST DATA CIRCUIT.

3-33. The lost data circuit causes a lost data indication to be generated when status or data transfers are not programmed and processed in the proper order. The circuit includes the Data-In-Register FF and the Lost Data FF. The

Data-In-Register FF and the Lost Data FF are cleared by the same signal that sets the Pick FF or by the CRS signal, if the computer preset switch is pressed. This ensures that both flip-flops are clear as each card starts through the read station. The set and clear inputs to the Data-In-Register FF are both tied to +4.85V so that the flip-flop changes state each time the clock goes through a high-to-low transition. This transition occurs at the trailing edge of the Strobe signal from gate U45D if the Data-In-Register FF is clear, or at the trailing edge of the IOI signal if the Data-In-Register FF is set. A Strobe signal is required to enable the data register. Therefore, the Data-In-Register FF is set each time the data register is loaded with a data word. An IOI signal is required to transfer the data register contents from the data register to the computer. So, the Data-In-Register FF is cleared each time a transfer has occurred. When the Data-In-Register FF is set, indicating that there is a data word in the data register, the high set-side output is applied to gates U33A and U23B. All the input signals to gate U33A being high cause the output to go low. The low output from gate U33A clears both the Flag Buffer FF and Flag FF. If an EOPI signal is generated or an I/O output instruction is processed to load a status word into the data register, while the Data-In-Register FF is set, the output of U23B will go low. This low output from gate U23B sets the Lost Data FF, indicating that the status information being sent to the computer is invalid. If the Data-In-Register FF is set or the Data signal is low, the "not" IOI signal is low at the time that the Strobe signal is low (indicating a data word is being transferred from the card reader), a low output will be generated at the output of gate U23D. This will set the Lost Data FF, indicating that the data word being sent to the computer is invalid. These conditions cause the Lost Data signal to be generated which provides a logic 1 at data register bit 3 (IOBI 3) during the status checking process.

3-34. STATUS SIGNAL CIRCUITS.

3-35. The status signal circuits condition the card reader status signals and develop the interface PCA status signals. Eight status signals are received from the card reader and five status signals (including the Lost Data signal explained in paragraph 3-28) are developed by the interface PCA. The relative bit positions of these status signals are shown in figure 3-2. All status signals coming from the card reader are first inverted by the status signal circuits and then routed to the status input gates of the data register. The "not" Hopper Empty signal, which indicates when the last card has been taken from the input hopper, is combined with the "not" Stacker Full signal, which indicates that the output stacker is carrying the maximum number of cards it can hold to provide status bit 5. The "not" Hopper Empty signal is also combined with the "not" End-of-File signal, which indicates that the end-of-file switch on the card reader has been pressed, to provide bit 7. The "not" Motion/Pick Check signal, which indicates that a card has not been stacked in the output stacker within the allotted length of time or that the card has not been picked from the input hopper after six attempts have been made, provides bit 11. The "not" Off-Line signal, which indicates that the OFF-LINE/ON-LINE switch on the card reader is




2210-4

Figure 3-2. Card Reader and Interface PCA Status Signals

in the OFF-LINE position, provides bit 2. The “not” Ready signal, which indicates that the card reader circuitry is in the proper state to start processing cards, is combined with the “not” Off-Line signal and the “not” Busy signal, which indicates that the card reader is currently processing a card,

provides status bit 0. Bit 0 will be high if the card reader is either not ready, busy, or off-line. The “not” Light Error signal, which indicates that the light sensors of the card reader read station are functioning properly, provides status bit 9.



4-1. INTRODUCTION.

4-2. This section contains information on diagnostics and troubleshooting for the card reader interface kit.

4-3. PREVENTIVE MAINTENANCE.

4-4. Detailed preventive maintenance procedures and schedules are provided in the applicable Hewlett-Packard computer documentation. There are no separate preventive maintenance procedures to be performed on the interface kit.

4-5. DIAGNOSTICS.

4-6. The interface PCA may be checked using the Diagnostic Program Procedures, part no. 02892-90006, contained in the *Manual of Diagnostics*. The diagnostic will check all of the status and data circuits on the interface card. This diagnostic test requires that the card reader be connected in the normal operating configuration.

4-7. TROUBLESHOOTING.

4-8. Troubleshooting for the interface PCA is accomplished by performing the tests in the diagnostic program and analyzing any error halts that occur as the test is being run. Continuity checks of the interconnecting cable are performed by using table 4-1. To further isolate the trouble, refer to the schematic diagram and parts location view in figure 4-1. Table 4-2 contains a parts list for the interface PCA with the parts listed in alphanumeric order by reference designation. Logic and pin location diagrams for the integrated circuits used on the interface PCA are contained in figure 4-2. Table 4-3 gives the integrated

circuit input levels, output levels, and delay times which correspond to the integrated circuit characteristic number shown below each diagram in figure 4-2.

Table 4-1. Cable Assembly Connector Pin Assignments


48-Pin Connector	50-Pin Connector	Signal Name	Card Reader Signal Mnemonic
1	A	Data Column 12	"not" D12
2	B	Data Column 11	"not" D11
3	C	Data Column 0	"not" D0
4	D	Data Column 1	"not" D1
5	K	Data Column 2	"not" D2
6	L	Data Column 3	"not" D3
7	M	Data Column 4	"not" D4
8	N	Data Column 5	"not" D5
9	U	Data Column 6	"not" D6
10	V	Data Column 7	"not" D7
11	W	Data Column 8	"not" D8
12	d	Data Column 9	"not" D9
15	X	Ready	"not" RDY
17	e	Hopper Empty	"not" HCK
18	y	Stacker Full	"not" STF
20	x	End-of-File	"not" EOF
21	z	Off-Line	"not" TEST
22	f	Pick Command	"not" PC
23	r	Index Mark	"not" IM
24/BB	CC/HH	Ground	GND
U	w	End-of-File Clear	"not" EOF CLEAR
V	n	Busy	"not" BSY
W	p	Motion/Pick Check	"not" MOCK
X	c	Error (light/dark)	"not" ERROR

4-9. CABLE ASSEMBLY CONNECTOR PIN FUNCTIONS.

4-10. Table 4-1 contains a list of cable assembly pin assignments for the interface PCA and the card reader connectors.

Table 4-2. Card Reader Interface PCA, Replaceable Parts

REFERENCE DESIGNATION	HP PART NO.	DESCRIPTION	MFR CODE	MFR PART NO.
C1,2,C8 thru C13, 15,C19 thru C22, C25 thru C28, C30 thru C33, C35 thru C40, C44 thru C48	0160-2055	CAPACITOR, fxd, cer, 0.01 uF, +80 - 20%, 100 Vdcw	56289	C023F101F103ZS22-CD
C3	0160-0939	CAPACITOR, fxd, Mica, 430 pF, 5%, 200 Vdcw	28480	0160-0939
C4,5,14,16,18	0160-0154	CAPACITOR, fxd, My, 2200 pF, 10%, 200 Vdcw	56289	192P22292-PTS
C6	0180-0137	CAPACITOR, fxd, Ta, 100 uF, 20%, 10 Vdcw	56289	5C10A7-CML
C7,17,23,24,29, 34,C41 thru C43, C49 thru C51	0180-0197	CAPACITOR, fxd, Ta, 2.2 uF, 10%, 20 Vdcw	56289	200P27
C52	0160-0153	CAPACITOR, fxd, My, 0.001 uF, 10%, 200 Vdcw	56289	192P10292-PTS
CR1	1910-0030	DIODE, Ge, 100 mA, 0.65V	14433	G694
CR2	1901-0081	DIODE, Si, 50V	07263	FD1415
Q1	1854-0071	TRANSISTOR, Si, NPN	01295	SKA1124
R1,2,3,34,36, 37,55	0689-3440	RESISTOR, fxd, flm, 196 ohms, 1%, 1/8W	28480	0689-3440
R4	0698-3158	RESISTOR, fxd, flm, 23.7k, 1%, 1/8W	28480	0698-3158
R5,7,9,11,13, 15,17,19,21, 23,25,27,29, 38,40,42,45, 47,49,50,52	0757-0416	RESISTOR, fxd, flm, 511 ohms, 1%, 1/8W	28480	0757-0416
R6,8,10,12,14, 16,18,20,22, 24,26,28,30, 39,41,43, 44,46,48, 51,53	0757-0274	RESISTOR, fxd, flm, 1.21k, 1%, 1/8W	28480	0757-0274
R32	0698-3445	RESISTOR, fxd, flm, 348 ohms, 1%, 1/8W	28480	0698-3445
R33	0757-0290	RESISTOR, fxd, flm, 6.19k ohms, 1%, 1/8W	28480	0757-0290
R35	0698-0082	RESISTOR, fxd, flm, 464 ohms, 1%, 1/8W	28480	0698-0082
R54,56	0698-3445	RESISTOR, fxd flm, 196 ohms, 1%, 1/8W	28480	0698-3445
R57,59	1810-0020	RESISTOR, network (7 fxd registers)	28480	1810-0020
R58,R60 thru R62	0757-0427	RESISTOR, fxd, flm, 1.50k, 1%, 1/8W	28480	0757-0427
U11,14,15	1820-0069	INTEGRATED CIRCUIT, TTL	01295	SN4344
U12,43,73,92	1820-0071	INTEGRATED CIRCUIT, TTL	01295	SN4345
U16,21,23, U24 thru U26, 32,36,45,53, 63,65,74, 82 thru 85, 94,105	1820-0054	INTEGRATED CIRCUIT, TTL	01295	SN4342
U17,27,37,47,57, 67,77,87,97,107	1820-0956	INTEGRATED CIRCUIT, CTL	07263	SL3459
U22	1820-0075	INTEGRATED CIRCUIT, TTL	01295	SN4353
U33 thru U35,44	1820-0068	INTEGRATED CIRCUIT, TTL	01295	SN4343
U42	1820-0207	INTEGRATED CIRCUIT, TTL	07263	SL4463
U46,55,66,75, 86,95	1820-0063	INTEGRATED CIRCUIT, TTL	01295	SN4348
U52,62,72,106	1820-0070	INTEGRATED CIRCUIT, TTL	01295	SN4345
U56,76,96	1820-0301	INTEGRATED CIRCUIT, TTL	01295	SN4463





2136-8


Figure 4-2. Integrated Circuit Diagrams


Table 4-3. Integrated Circuit Characteristics

CHARACTERISTIC	INPUT LEVEL		OUTPUT LEVEL		OPEN INPUT ACTS AS:	MAXIMUM PROPAGATION DELAY	
	LOGIC 1 (VOLTS, MIN)	LOGIC 0 (VOLTS, MAX)	LOGIC 1 (VOLTS, MIN)	LOGIC 0 (VOLTS, MAX)		TO LOGIC 1 (NANOSECONDS)	TO LOGIC 0 (NANOSECONDS)
2	+2.0	+0.8	+2.4	+0.4	Logic 1	29	15
7	+2.0	+0.8	+2.4	+0.4	Logic 1	50	50
9	+2.0	+0.8	+2.4	+0.4	Logic 1	40	25
17	+1.25	+0.5	+2.25	-0.36	Logic 0	18	18
48	+1.9	+0.85	+2.4	+0.45	Logic 1	40	—



- NOTES:
- 1. RESISTANCE VALUES ARE IN OHMS AND CAPACITANCE VALUES IN MICROFARADS UNLESS OTHERWISE SPECIFIED.
 - 2. ALL LOGIC IS POSITIVE TRUE.
 - 3. AN ASTERISK (*) DENOTES PINS ON THE 48 PIN CONNECTOR. ALL OTHER PINS ARE ON THE 86-PIN CONNECTOR.
 - 4. SCHEMATIC DIAGRAM FOR RESISTOR NETWORKS R1 AND R2:





5-1. INTRODUCTION.

5-2. This section contains information for ordering replacement parts for the HP 12924A Card Reader Interface Kit. Table 5-1 lists parts in alphanumeric order by HP part number and lists the following information for each part.

- a. Description of the part. (Refer to table 5-3 for an explanation of abbreviations and reference designations used in the DESCRIPTION column.)
- b. Typical manufacturer of the part in a five-digit code; refer to the list of manufacturers in table 5-2.
- c. Manufacturer's part number.
- d. Total quantity of each part used in the interface kit.

5-3. A separate parts list is provided along with the parts location view for the interface card in section IV of this manual. This parts list presents the parts in alphanumeric order by reference designation.

5-4. ORDERING INFORMATION.

5-5. To order replacement parts, address the order or inquiry to the local Hewlett-Packard Sales and Service Office. (Refer to the list at the end of this manual for addresses.) Specify the following information for each part ordered:

- a. Unit model and serial number.
- b. Hewlett-Packard stock number for each part.
- c. Description of each part.
- d. Circuit reference designation.

Table 5-1. Card Reader Interface Kit Replaceable Parts

HP PART NO.	DESCRIPTION	MFR CODE	MFR PART NO.	TQ
0160-0153	CAPACITOR, fxd, My, 0.001 μ F, 10%, 20 Vdcw	56289	192P10292-PTS	1
0160-0154	CAPACITOR, fxd, My, 2200 pF, 10%, 200 Vdcw	28480	0160-0154	5
0160-0939	CAPACITOR, fxd, Mica, 430 pF, 5%, 200 Vdcw	28480	0160-0939	1
0160-2055	CAPACITOR, fxd, cer, 0.01 μ F, +80 -20%, 100 Vdcw	56289	C023F101F103ZS22-CD	32
0180-0137	CAPACITOR, fxd, Ta, 100 μ F, 20%, 10 Vdcw	28480	0180-0137	1
0180-0197	CAPACITOR, fxd, Ta, 2.2 μ F, 10%, 20 Vdcw	28480	0180-0197	12
0698-0082	RESISTOR, fxd, flm, 464 ohms, 1%, 1/8W	28480	0698-0082	1
0698-3158	RESISTOR, fxd, flm, 23.7k ohms, 1%, 1/8W	28480	0698-3158	1
0698-3440	RESISTOR, fxd, flm, 196 ohms, 1%, 1/8W	28480	0698-3440	7
0698-3445	RESISTOR, fxd, flm, 348 ohms, 1%, 1/8W	28480	0698-3445	2
0757-0274	RESISTOR, fxd, flm, 1.21k, 1%, 1/8W	28480	0757-0274	22
0757-0290	RESISTOR, fxd, flm, 6.19k ohms, 1%, 1/8W	28480	0757-0290	1
0757-0416	RESISTOR, fxd, flm, 511 ohms, 1%, 1/8W	28480	0757-0416	22
0757-0427	RESISTOR, fxd, flm, 1.50k, 1%, 1/8W	28480	0757-0427	4
1810-0020	RESISTOR, network (7 fxd flm resistors)	28480	1820-0020	2
1820-0054	INTEGRATED CIRCUIT, TTL	01295	SN4342	19
1820-0063	INTEGRATED CIRCUIT, TTL	01295	SN4348	6
1820-0068	INTEGRATED CIRCUIT, TTL	01295	SN4343	4
1820-0069	INTEGRATED CIRCUIT, TTL	01295	SN4344	3
1820-0070	INTEGRATED CIRCUIT, TTL	01295	SN4345	4
1820-0071	INTEGRATED CIRCUIT, TTL	01295	SN4345	4
1820-0075	INTEGRATED CIRCUIT, TTL	01295	SN4353	1
1820-0207	INTEGRATED CIRCUIT, TTL	07263	SL12895	1
1820-0301	INTEGRATED CIRCUIT, TTL	01295	SN4463	3
1820-0956	INTEGRATED CIRCUIT, CTL	07263	SL3459	10
1854-0071	TRANSISTOR, Si, NPN	01295	SKA1124	1
1901-0081	DIODE, Si, 50V	07263	FD1415	1
1910-0030	DIODE, Ge, 100 mA, 0.65V	14433	G694	1
12924-60001	CARD READER INTERFACE PRINTED-CIRCUIT ASSEMBLY	28480	12924-60001	1
12924-60002	CABLE ASSEMBLY	28480	12924-60002	1
12924-90001	CARD READER INTERFACE KIT OPERATING AND SERVICE MANUAL	28480	12924-90001	1

Table 5-2. Code List of Manufacturers

The following code numbers are from the Federal Supply Code for Manufacturers Cataloging Handbooks H4-1 and H4-2, and the latest supplements.					
Code No.	Manufacturer	Address	Code No.	Manufacturer	Address
01295	Texas Instruments, Inc.		28480	Hewlett-Packard Co.	Palo Alto, Cal.
	Transistor Products Division	Dallas, Texas	14433	ITT Semiconductor, a Div. of Int.	
07263	Fairchild Camera & Inst. Corp.,			Telephone and Telegraph	West Palm Beach, Fla.
	Semiconductor Division	Mt. View, Cal.	56289	Sprague Electric Co.	North Adams, Mass.

Table 5-3. Reference Designations and Abbreviations

REFERENCE DESIGNATIONS					
A	= assembly	K	= relay	TB	= terminal board
B	= motor, synchro	L	= inductor	TP	= test point
BT	= battery	M	= meter	U	= integrated circuit, non-repairable assembly
C	= capacitor	P	= plug connector	V	= vacuum tube, photocell, etc.
CB	= circuit breaker	Q	= semiconductor device other than diode or integrated circuit	VR	= voltage regulator
CR	= diode	R	= resistor	W	= jumper wire
DL	= delay line	RT	= thermistor	X	= socket
DS	= indicator	S	= switch	Y	= crystal
E	= Misc electrical parts	T	= transformer	Z	= tuned cavity, network
F	= fuse				
FL	= filter				
J	= receptacle connector				

ABBREVIATIONS					
A	= amperes	gra	= gray	PCA	= printed-circuit assembly
ac	= alternating current	grn	= green	PWB	= printed-wiring board
Ag	= silver			phh	= phillips head
Al	= aluminum	H	= henries	pk	= peak
ar	= as required	Hg	= mercury	p-p	= peak-to-peak
adj	= adjust	hr	= hour(s)	pt	= point
assy	= essembly	Hz	= hertz	prv	= peak inverse voltage
		hdw	= hardware	PNP	= positive-negative-positive
b	= base	hex	= hexagon, hexagonal	pwv	= peak working voltage
bp	= bandpass	ID	= inside diameter	porc	= porcelain
bpi	= bits per inch	IF	= intermediate frequency	posn	= position(s)
blk	= black	in.	= inch, inches	pozi	= pozidrive
blu	= blue	I/O	= input/output		
brn	= brown	int	= internal	rf	= radio frequency
brs	= brass	incl	= include(s)	rdh	= round head
Btu	= British thermal unit	insul	= insulation, insulated	rms	= root-mean-square
Be Cu	= beryllium copper	impgrg	= impregnated	rww	= reverse working voltage
		incand	= incandescent	rect	= rectifier
cpi	= characters per inch	ips	= inches per second	r/min	= revolutions per minute
coll	= collector			RTL	= resistor-transistor logic
cw	= clockwise	k	= kilo (10 ³), kilohm		
ccw	= counterclockwise	lp	= low pass	s	= second
cer	= ceramic	m	= milli (10 ⁻³)	SB, TT	= slow blow
com	= common	M	= mega (10 ⁶), megohm	Se	= selenium
crt	= cathode-ray tube	My	= Mylar	Si	= silicon
CTL	= complementary-transistor logic	mfr	= manufacturer	scr	= silicon controlled rectifier
cath	= cathode	mom	= momentary	sst	= stainless steel
Cd pl	= cadmium plate	mtg	= mounting	stl	= steel
comp	= composition	misc	= miscellaneous	spcl	= special
conn	= connector	met. ox.	= metal oxide	spdt	= single-pole, double-throw
compl	= complete	mintr	= miniature	spst	= single-pole, single-throw
dc	= direct current	n	= nano (10 ⁻⁹)	Ta	= tantalum
dr	= drive	nc	= normally closed or no connection	td	= time delay
DTL	= diode-transistor logic	Ne	= neon	Ti	= titanium
depc	= deposited carbon	no.	= number	tgl	= toggle
dpdt	= double-pole, double-throw	n.o.	= normally open	thd	= thread
dpst	= double-pole, single-throw	np	= nickel plated	tol	= tolerance
		NPN	= negative-positive-negative	TTL	= transistor transistor logic
em	= emitter	NPO	= negative-positive zero (zero temperature coefficient)		
ECL	= emitter-coupled logic	NSR	= not separately replaceable	U(μ)	= micro (10 ⁻⁶)
ext	= external	NRFR	= not recommended for field replacement	V	= volt(s)
encap	= encapsulated			var	= variable
elctlt	= electrolytic			vio	= violet
				Vdcw	= direct current working volts
F	= farads	OD	= outside diameter	W	= watts
FF	= flip-flop	OBD	= order by description	ww	= wirewound
flh	= flat head	orn	= orange	wht	= white
flm	= film	ovh	= oval head	WIV	= working inverse voltage
fxd	= fixed	oxd	= oxide		
filh	= fillister head			yel	= yellow
G	= giga (10 ⁹)	p	= pico (10 ⁻¹²)		
Ge	= germanium	PC	= printed circuit		
gl	= glass				
gnd	= ground(ed)				

ELECTRONIC

SALES & SERVICE OFFICES

UNITED STATES

ALABAMA

P.O. Box 4207
2003 Byrd Spring Road S.W.
Montevallo 35802
Tel: (205) 881-4591
TWX: 610-726-2204

ARIZONA

2336 E. Magnolia St.
Phoenix 85034
Tel: (602) 252-5061
TWX: 910-951-1330

5737 East Broadway
Tucson 85716
Tel: (602) 286-2313
TWX: 910-952-1162

CALIFORNIA

1430 East Orangewood Ave.
Fellerton 92831
Tel: (714) 870-1000

3939 Lankershim Boulevard
North Hollywood 91604
Tel: (213) 877-1262
TWX: 810-499-2170

1101 Embarcadero Road
Palo Alto 94303
Tel: (415) 327-6500
TWX: 810-373-1260

2220 Watt Ave.
Sacramento 95625
Tel: (916) 462-1463
TWX: 810-367-2092

9606 Aero Drive
San Diego 92123
Tel: (714) 278-3200
TWX: 810-335-2000

COLORADO

7965 East Prentice
Englewood 80110
Tel: (303) 771-3455
TWX: 910-935-0705

CONNECTICUT

12 Lunar Drive
New Haven 06525
Tel: (203) 389-6551
TWX: 710-465-2029

FLORIDA

P.O. Box 24210
2806 W. Oakland Park Blvd.
Ft. Lauderdale 33307
Tel: (305) 731-2020
TWX: 510-955-4099

P.O. Box 13910
6177 Lake Eleanor Dr.
Orlando 32809
Tel: (305) 859-2900
TWX: 810-850-0113

GEORGIA

P.O. Box 26234
450 Interstate North
Atlanta 30328
Tel: (404) 436-6161
TWX: 810-766-4890

ILLINOIS

5500 Howard Street
Skokie 60076
Tel: (312) 677-0400
TWX: 910-223-3613

INDIANA

3839 Meadows Drive
Indianapolis 46205
Tel: (317) 546-4681
TWX: 610-341-3263

LOUISIANA

P.O. Box 856
1942 Williams Boulevard
Kenner 70062
Tel: (504) 721-6201
TWX: 610-855-5524

MARYLAND

6707 Whitestone Road
Baltimore 21207
Tel: (301) 944-5400
TWX: 710-862-9157

P.O. Box 1648
2 Choke Cherry Road
Rockville 20860
Tel: (301) 948-6370
TWX: 710-628-9684

MASSACHUSETTS

32 Hortwell Ave.
Lexington 02173
Tel: (617) 861-8960
TWX: 710-326-6904

MICHIGAN

21840 West Nine Mile Road
Southfield 48075
Tel: (313) 353-9100
TWX: 610-224-4882

MINNESOTA

2459 University Avenue
St. Paul 55114
Tel: (612) 645-9461
TWX: 910-563-3734

MISSOURI

11131 Colorado Ave.
Kansas City 64137
Tel: (816) 763-8000
TWX: 810-771-2087

148 Weldon Parkway
Maryland Heights 63043
Tel: (314) 587-1455
TWX: 910-764-0630

NEW JERSEY

W. 120 Century Road
Paramus 07652
Tel: (201) 265-5000
TWX: 910-990-4951

1060 N. Kings Highway
Cherry Hill 08034
Tel: (609) 667-4000
TWX: 710-822-4945

NEW MEXICO

P.O. Box 8368
Station C
6501 Lomas Boulevard N.E.
Albuquerque 87108
Tel: (505) 265-3713
TWX: 910-969-1665

156 Wyatt Drive
Las Cruces 88001
Tel: (505) 526-2485
TWX: 910-983-0550

NEW YORK

1702 Central Avenue
Albany 12205
Tel: (518) 869-8462
TWX: 710-441-8270

1219 Campville Road
Endicott 13760
Tel: (607) 754-0050
TWX: 510-252-0690

82 Washington Street
Poughkeepsie 12601
Tel: (914) 464-7330
TWX: 510-248-0012

39 Saginow Drive
Rochester 14623
Tel: (716) 473-9500
TWX: 510-253-5981

5858 East Molloy Road
Syracuse 13211
Tel: (315) 454-2486
TWX: 710-541-0482

1 Crosway Park West
Woodbury 11797
Tel: (516) 921-0300
TWX: 510-223-0811

NORTH CAROLINA

P.O. Box 5188
1923 North Main Street
High Point 27262
Tel: (818) 885-8101
TWX: 510-926-1516

OHIO

25575 Canter Ridge Road
Cleveland 44145
Tel: (216) 835-0300
TWX: 610-427-9128

3460 South Dixie Drive
Dayton 45438
Tel: (513) 298-0351
TWX: 810-459-1925

1120 Morse Road
Columbus 43229
Tel: (614) 848-1300

OKLAHOMA

2919 United Founders Boulevard
Oklahoma City 73112
Tel: (405) 848-2801
TWX: 910-630-6662

OREGON

Westhills Mall, Suite 158
4475 S.W. Schollie Ferry Road
Portland 97225
Tel: (503) 292-9171
TWX: 510-464-6103

PENNSYLVANIA

2500 Moss Side Boulevard
Monroeville 15146
Tel: (412) 271-0724
TWX: 710-797-3650

1021 8th Avenue
King of Prussia Industrial Park
King of Prussia 19406
Tel: (215) 285-7000
TWX: 510-660-2670

RHODE ISLAND

873 Waterman Ave.
East Providence 02914
Tel: (401) 434-5535
TWX: 710-381-7573

*TENNESSEE

Momphis
Tel: (601) 274-7472

TEXAS

P.O. Box 1270
201 E. Arapaho Rd.
Richardson 75080
Tel: (214) 231-6101
TWX: 810-867-4723

P.O. Box 27409
6300 Westpark Drive
Suite 100
Houston 77027
Tel: (713) 781-6000
TWX: 910-881-2645

231 Billy Mitchell Road
San Antonio 78226
Tel: (512) 434-4171
TWX: 910-871-1170

UTAH

2690 South Main Street
Salt Lake City 84115
Tel: (801) 487-0715
TWX: 910-925-5661

VERMONT

P.O. Box 2287
Kannedy Drive
South Burlington 05401
Tel: (802) 656-4455
TWX: 510-299-0025

VIRGINIA

P.O. Box 6514
2111 Spencer Road
Richmond 23230
Tel: (703) 285-3431
TWX: 710-856-0157

WASHINGTON

433-108th N.E.
Bellevue 98004
Tel: (206) 454-3971
TWX: 910-443-2303

*WEST VIRGINIA

Charleston
Tel: (304) 768-1232

FOR U.S. AREAS NOT LISTED:

Contact the regional office nearest you: Atlanta, Georgia... North Hollywood, California... Peromus, New Jersey... Skokie, Illinois. Their complete addresses are listed above.

*Service Only

CANADA

ALBERTA

Hewlett-Packard (Canada) Ltd.
11748 Kingsway Ave.
Edmonton
Tel: (403) 452-3670
TWX: 610-831-2431

BRITISH COLUMBIA

Hewlett-Packard (Canada) Ltd.
4519 Canade Way
North Burnaby 2
Tel: (604) 433-8213
TWX: 610-922-5059

MANITOBA

Hewlett-Packard (Canada) Ltd.
513 Century St.
Winnipeg
Tel: (204) 786-7581
TWX: 610-871-3531

NOVA SCOTIA

Hewlett-Packard (Canada) Ltd.
2745 Dutch Village Rd.
Suite 206
Halifax
Tel: (902) 455-0511
TWX: 610-271-4482

ONTARIO

Hewlett-Packard (Canada) Ltd.
1785 Woodward Dr.
Ottawa 3
Tel: (613) 255-6180, 255-6530
TWX: 610-562-1952

Hewlett-Packard (Canada) Ltd.

50 Gelsey Blvd.
Rexdale
Tel: (416) 677-9611
TWX: 610-492-4246

QUEBEC

Hewlett-Packard (Canada) Ltd.
275 Hymus Boulevard
Pointe Claire
Tel: (514) 687-4232
TWX: 610-422-3022
Telox: 01-20607

FOR CANADIAN AREAS NOT LISTED:

Contact Hewlett-Packard (Canada) Ltd. in Pointe Claire, or the complete address listed above.

CENTRAL AND SOUTH AMERICA

ARGENTINA

Hewlett-Packard Argentina
S.A.C.A.I
Lavalle 1171 - 3°
Buenos Aires
Tel: 35-0436, 35-0627, 35-0431
Telox: 012-1009
Cable: HEWPACK ARG

BRAZIL

Hewlett-Packard Do Brasil
L.C. Ltda.
Rua Frei Caneca 1119
Sao Paulo - 3, SP
Tel: 288-7111, 287-5668
Cable: HEWPACK Sao Paulo

Hewlett-Packard Do Brasil
Prace Dom Feliciano 76
Sao Paulo 060/808

Porto Alegre
Rio Grande do Sul (RS)-Brasil
Tel: 25-8470
Cable: HEWPACK Porto Alegre

Hewlett-Packard Do Brasil
L.C. Ltda.
Rua da Metriz 29
Botafogo 20-02
Rio de Janeiro, CB
Tel: 246-4417, 246-2919
Cable: HEWPACK Rio de Janeiro

CHILE

Héctor Calcegni y Cia. Ltda.
Bustos, 1932-3or Piso
Casilla 13942
Santiago
Tel: 423 98
Cable: CALCAGNI Santiago

COLOMBIA

Instrumotocion
Henrik A. Langebeek & Kier S.A.
Carrera 7 No. 48-39
Aptado Aereo 6267
Bogota, 1 O.E.
Tel: 45-76-06, 45-55-46
Cable: AARIS Bogota
Telox: 44400INSTCO

COSTA RICA

Lic. Alfredo Gallago Gurdien
Apartado 10169
San José
Tel: 21-66-13
Cable: CALGUR San José

ECUADOR

Laboratorio de Radio-Ingenieria
Calle Guayaquil 1246
Post Office Box 3199
Quito
Tel: 212-496; 219-165
Cable: HORVATH Quito

EL SALVADOR

Electronic Associates
Aptado Postal 1682
Centro Comercial Gigento
San Salvador, El Salvador C.A.
Paseo Escalon 4649-4° Piso
Tel: 23-44-60, 23-32-37
Cable: ELECAS

GUATEMALA

IPESA
5a via 2-01, Zone 4
Guatemala City

MEXICO

Hewlett-Packard Mexicana, S.A.
de C.V.
622 Adolfo Prieto
Col. del Valle
Mexico 12, O.F.
Tel: 543-4232; 623-1674
Telox: 017-74-507

NICARAGUA

Roberto Tarán G.
Aptado Postal 689
Edificio Torón
Managua
Tel: 3451, 3452
Cable: ROTERAN Managua

PANAMA

Electrónico Balboa, S.A.
P.O. Box 4929
Ave. Manuel Espinosa No. 13-50
Bldg. Alina
Panama City
Tel: 230833
Telox: 3461003, Curundu,
Cable Zone
Cable: ELECTRON Panama City

PARAGUAY

Z.T. Melamed S.R.L.
División: Aparatos y Equipos
Medicos
Salon de Exposición y Escritorio
Chile 482
Edificio Victoria—Plante Beje
Asunción, Paraguay
Tel: 4-5065, 4-6272
Cable: RAMEL

PERU

Compañía Electro Medica S.A.
Ave. Enrique Ceneval 312
San Isidro
Casilla 1030
Lima
Tel: 22-3900
Cable: ELMEO Lima

PUERTO RICO

San Juan Electronica, Inc.
P.O. Box 5167
Ponca de Leon 154
Pda. 3-PTA de Tierra
San Juan 00906
Tel: (808) 725-3342, 722-3342
Cable: SATRONICS San Juan
Telox: SATRON 3450 S32

URUGUAY

Pablo Farrando S.A.
Comercial e Industrial
Avenida Italia 2877
Casilla de Correo 370
Montevideo
Tel: 40-3102
Cable: RADIUM Montevideo

VENEZUELA

Hewlett-Packard De Venezuela
C.A.
Aptado 50933
Caracas
Tel: 71.88.05, 71.88.69, 71.99.30
Cable: HEWPACK Caracas
Telox: 21146 HEWPACK

FOR AREAS NOT LISTED,

CONTACT:
Hewlett-Packard
INTERCONTINENTAL
3200 Hillview Ave.
Palo Alto, California 94304
Tel: (415) 493-1501
TWX: 910-373-1267
Cable: HEWPACK Palo Alto
Telox: 034-8300, 034-8493

EUROPE

AUSTRIA
Hawlett-Packard Ges.m.b.H
Innstrasse 23/2
Postfach 45
A-1204 Vienna
Tel: (0222) 33 68 06 to 09
Cable: HEWPAK Vienne
Talex: 75923 hewpek a

BELGIUM
Hawlett-Packard Benelux
S.A./H.V.
Avenue du Col-Vert, 1
B-1170 Brussels
Tel: (02) 72 22 40
Cable: PALOBEH Brussels
Talex: 23 494

DENMARK
Hawlett-Packard A/S
Oatavaj 38
OK-3460 Birkarod
Tel: (01) 81 68 40
Cable: HEWPAK AS
Talex: 16640 hp as
Hawlett-Packard A/S
Torvet 9
OK-8600 Silkeborg
Tel: (06) 82-71-66
Talex: 16840 hp as
Cable: HEWPAKAS

FINLAND
Hawlett-Packard Oy
Bulavard 26
P.O. Box 12165
SF-00120 Helsinki 12
Tel: 13-730
Cable: HEWPAKOV-Helsinki
Talex: 17-1563 hel

FRANCE
Hawlett-Packard France
Quartier de Courtois
Boite Postale No. 8
F-81 Orsay
Tel: (1) 907 78 25
Cable: HEWPAK Orsay
Talex: 60048

Hawlett-Packard France
4 Quai des Etrols
F-69 Lyon 5ème
Tel: (76) 42 63 45
Cable: HEWPAK Lyon
Talex: 31617

Hawlett-Packard France
2 rue de la Gare
F-31 Blagnac
Tel: (61) 85 82 29
Talex: 51957

GERMAN FEDERAL REPUBLIC
Hawlett-Packard Vertriebs-GmbH
Berliner Strasse 117
Postfach 560 140
Tel: (0611) 50-04-1
Cable: HEWPAKSA Frankfurt
Talex: 41 32 49 FRA

Hawlett-Packard Vertriebs-GmbH
Herrenbergerstrasse 110
D-7030 Böblingen, Württemberg
Tel: (07031) 66 72 86-87
Cable: HEPAK Böblingen
Talex: 72 65 739 bbn

Hawlett-Packard Vertriebs-GmbH
Vogelsanger Weg 38
D-4 Düsseldorf
Tel: (0211) 63 80 31/35
Talex: 85/86 533 hdd d

Hawlett-Packard Vertriebs-GmbH
Wendlandstr. 23
D-2 Hamburg 1
Tel: (0411) 24 05 51/52
Cable: HEWPAKSA Hamburg
Talex: 21 53 32 hph d

Hawlett-Packard Vertriebs-GmbH
Unterhochinger Strasse 28
ISAR Center
D-8012 Otterbrunn
Tel: (0611) 60 13 081-7
Talex: 52 49 65
Cable: HEWPAKSA München

(West Berlin)
Hawlett-Packard Vertriebs-GmbH
Wilmsdorfer Strasse 113/114
D-1000 Berlin W. 12
Tel: (0311) 3137046
Talex: 16 34 05 hpbm d

GREECE
Kostas Koryennis
18, Ermou Street
Athens 126
Tel: 3230-303
Cable: RAKAR Athens
Talex: 21 58 62 rkar gr

IRELAND
Hawlett-Packard Ltd.
224 Bath Road
Slough, SL1 4 05, Bucks
Tel: Slough 753-33341
Cable: HEWPIE Slough
Talex: 84413

ITALY
Hawlett-Packard Italiana S.p.A.
Via Amerigo Vesputci 2
I-20124 Milan
Tel: (2) 6251 (10 lines)
Cable: HEWPAKIT Milan
Talex: 32046

Hawlett-Packard Italiana S.p.A.
Piazza Marconi
I-00144 Rome - Eur
Tel: (6) 5912544/5, 5915947
Cable: HEWPAKIT Roma
Talex: 61514

Hawlett-Packard Italiana S.p.A.
Vicolo Pastori, 3
I-35100 Padova
Tel: (49) 66 40 62
Talex: 32046 via Milan

Hawlett-Packard Italiana S.p.A.
Vie Colla, 24
I-10129 Turin
Tel: (11) 53 82 64
Talex: 32046 via Milan

LUXEMBURG
Hawlett-Packard Benelux
S.A./H.V.
Avenue du Col-Vert, 1
B-1170 Brussels
Tel: (03) 02 72 22 40
Cable: PALOBEH Brussels
Talex: 23 494

NETHERLANDS
Hawlett-Packard Benelux, N.V.
Wardasteln 117
P.O. Box 7625
Amsterdam, Z 11
Tel: 020-42 77 77
Cable: PALOBEH Amsterdam
Talex: 13 216 hapa nl

NORWAY
Hawlett-Packard Horga A/S
Box 149
Nesvæn 13
H-1344 Haslum
Tel: (02)-53 83 60
Talex: 16821

PORTUGAL
Talcitra-Empresa Tecnica de Equipamentos
Electricos S.a.r.l.
Rua Rodrigo da Fonseca 103
P.O. Box 2531
P-Lisbon 1
Tel: (19) 68 60 72
Cable: TELETRA Lisbon
Talex: 1598

SPAIN
Hawlett-Packard Española, S.A.
Jeraz No 8
Madrid 16
Tel: 458 26 00
Talex: 23515 hpe

Hawlett-Packard Española, S.A.
Milaneda 21-23
E-Barcelona 17
Tel: (3) 203 62 00

SWEEN
Hawlett-Packard Sveriga AB
Enlghetavägen 1-3
Fack
S-161 20 Bromma 20
Tel: (08) 98 12 50
Cable: MEASUREMETS
Stockholm
Talex: 10721

Hawlett-Packard Svarige AB
Hagakarsgratan 9C
S-431 41 Mölndal
Tel: (031) 27 66 00/01
Talex: 21 312 hpmindl s

SWITZERLAND
Hawlett Packard (Schweiz) AG
Zürcherstrasse 20
P.O. Box 64
CH-8952 Schlieren Zurich
Tel: (01) 98 16 21/24
Cable: HPAG CH
Talex: 53933

Hawlett-Packard (Schweiz) AG
Rue du Bois-du-Lan 7
P.O. Box 85
1217 Meyrin 2 Geneva
Tel: (022) 41 54 00
Cable: HEWPAKSA Geneva
Talex: 27333 hpsa ch

TURKEY
Telekom Engineering Bureau
P.O. Box 376
Karaköy
Istanbul
Tel: 458 40 40
Cable: TELEMATION Istanbul

UNITED KINGDOM
Hawlett-Packard Ltd.
224 Bath Road
Slough, SL1 4 05, Bucks
Tel: Slough (0753) 33341
Cable: HEWPIE Slough
Talex: 84413
Hawlett-Packard Ltd.
"The Graftons"
Stamford Haw Road
Altrincham, Cheshire
Tel: (061) 928-6628
Talex: 668066

SOCIALIST COUNTRIES PLEASE CONTACT:
Hawlett-Packard Gaa.m.b.H
Innstrasse 23/2
Postfach 45
A-1204 Vienna, Austria
Tel: (0222) 33 66 06-09
Cable: HEWPAK Vienna
Talex: 75923 hewpak e

ALL OTHER EUROPEAN COUNTRIES CONTACT:
Hawlett-Packard S.A.
Rue du Bois-du-Lan 7
P.O. Box 85
CH-1217 Meyrin 2 Geneva
Switzerland
Tel: (022) 41 54 00
Cable: HEWPAKSA Geneva
Talex: 2.24.86

AFRICA, ASIA, AUSTRALIA

ANGOLA
Talcitra Empresa Técnica
da Equipamentos Eléctricos
SAR
Rue de Barbosa Rodrigues
42-1°
Box 6487
Luanda
Cable: TELETRA Luanda

AUSTRALIA
Hawlett-Packard Australia
Pty. Ltd.
22-26 Weir Street
Glan Iris, 3140
Victoria
Tel: 20-1371 (6 lines)
Cable: HEWPARO Melbourne
Talex: 31 024

Hawlett-Packard Australia
Pty. Ltd.
61 Alexander Street
Crawa Mast 2065
Haw South Wales
Tel: 43-7868
Cable: HEWPARO Sydney
Talex: 21561

Hawlett-Packard Australia
Pty. Ltd.
97 Churchill Road
Prospect 5082
South Australia
Tel: 65-2368
Cable: HEWPARO Adelaide

Hawlett Packard Australia
Pty. Ltd.
2nd Floor, Suite 13
Casablanca Buildings
188 Adelaide Terrace
Perth, W.A. 8000
Tel: 21-3330
Cable: HEWPARO Perth

Hawlett-Packard Australia
Pty. Ltd.
10 Woolley Street
P.O. Box 191
Bickton A.C.T. 2802
Tel: 49-6194
Cable: HEWPARO Canberra ACT
Hawlett-Packard Australia
Pty. Ltd.
6 Harvard Street
P.O. Box 135
Kammar 4069 Queensland
Tel: 70-4050

CEYLON
United Electricals Ltd.
P.O. Box 661
Yehala Building
Staples Street
Colamba 2
Tel: 5496
Cable: HOTPOINT Colombo

CYPRUS
Kyprios
19 Gregorios & Xanopoulos Road
P.O. Box 1152
Hicelie
Tel: 6262-75626
Cable: HE-1-HAMI

ETHIOPIA
African Salespewer & Agency
Private Ltd., Co.
P.O. Box 718
56/59 Cunningham St.
Addis Ababa
Tel: 12285
Cable: ASACO Addisababa

HONG KONG
Schmidt & Co. (Hong Kong) Ltd.
P.O. Box 297
1511, Prince's Building 15th Floor
10, Chater Road
Hong Kong
Tel: 240188, 232735
Cable: SCHMIOTCO Hong Kong

INDIA
Blue Star Ltd.
Kasturi Buildings
Jamshedji Tata Rd.
Bombay 20BR, India
Tel: 29 50 21
Talex: 3751
Cable: BLUEFOST

Blue Star Ltd.
Band Box House
Prabhadevi
Bombay 2500, India
Tel: 45 73 01
Talex: 3751
Cable: BLUESTAR

Blue Star Ltd.
14/40 Civil Lines
Kanpur, India
Tel: 6 86 62
Cable: BLUESTAR

Blue Star Ltd.
7 Hara Street
P.O. Box 508
Calcutta 1, India
Tel: 23-0131
Talex: 655
Cable: BLUESTAR

Blue Star Ltd.
Blue Star House,
34 Ring Road
Lajpet Nagar
New Delhi 24, India
Tel: 62 32 76
Talex: 463
Cable: BLUESTAR

Blue Star Ltd.
Blue Star House
11/11A Magarath Road
Bangalore, 25
Tel: 51473
Talex: 430
Cable: BLUESTAR

Blue Star, Ltd.
1-1-117/1
Sarajini Devi Road
Secunderabad 3
Tel: 7 63 91, 7 73 93
Cable: BLUEFOST

Blue Star, Ltd.
23/24 Second Line Beach
Madras 1, India
Tel: 2 39 55
Talex: 379
Cable: BLUESTAR

Blue Star, Ltd.
18 Kaiser Bungalow
Oldind Road
Jamshedpur, India
Tel: 38 04
Cable: BLUESTAR

INDONESIA
Bah Bolton Trading Coy. H.V.
Ojalah Merdeka 29
Bandung
Tel: 4915; 51560
Cable: ILMU
Talex: 08-809

IRAN
Multicorp International Ltd.
Avenue Sorey 130
P.O. Box 1212
Tehran
Tel: B3 10 35-39
Cable: MULTICORP Tehran
Talex: 2876 service tn

ISRAEL
Electronics & Engineering
Olv. of Meteorita Israel Ltd.
17 Aminadav Street
Tel-Aviv
Tel: 36941 (3 lines)
Cable: BASTEL Tel-Aviv
Talex: MOTIL IL

JAPAN
Yokogawa-Hawlett-Packard Ltd.
Ohashi Building
1-59-1 Yoyogi
Shibuya-ku, Tokyo
Tel: 03-370-2261/82
Talex: 232-2024YHP
Cable: YHPMARKET TOK 23-724

Yokogawa-Hawlett-Packard Ltd.
Hisei Ibaragi Bldg.
2-6 Kasuga
Ibaragi-Shi
Osaka
Tel: (0728) 23-1641
Talex: 5332-385 YHP OSAKA

Yokogawa-Hawlett-Packard Ltd.
Ito Building
Ho. 58, Kotori-cho
Hakamura-ku, Nagoya City
Tel: (052) 551-0215

Yokogawa-Hawlett-Packard Ltd.
Hitto Bldg.
2-42 Shinhohara-Kita
Kohoku-ku
Yokohama 222
Tel: 045-432-1504
Talex: 382-3204 YHP YOK

JORDAN
Constantin E. Macridis
Clemenceau Street
P.O. Box 7213
Baikut, Labanon
Tel: 220846
Cable: ELECTROHUCLEAR Baikut

KENYA
Kenya Kinetics
P.O. Box 16311
Hirodi, Kenya
Tel: 57726
Cable: PROTOH

KOREA
Amtraco Corporation
Industrial Products Olv.
Seoul P.O. Box 1103
6th floor, OaeKyung Bldg.
107 Sejong Ro
Chongro-Ku, Seoul
Tel: 69-824-7
Cable: AMTRACO Seoul

LEBANON
Constantin E. Macridis
Clemenceau Street
P.O. Box 7213
Baikut
Tel: 220846
Cable: ELECTROHUCLEAR Baikut

MALAYSIA
MECOMB Malaysia Ltd.
2 Loreng 13/6A
Section 13
Pataing Jaya, Salangor
Cable: MECOMB Kuala Lumpur

MOZAMBIQUE
A. H. Goncalves, LOA.
4.1 Apt. 14 Av. D. Luis
P.O. Box 107
Lourenço Marques
Cable: HEGOH

NEW ZEALAND
Hawlett-Packard (H.Z.) Ltd.
94-96 Olxson St.
P.O. Box 9443
Wellington, N.Z.
Tel: 58-559
Cable: HEWPAK Wellington

Hawlett-Packard (H.Z.) Ltd.
Box 51092
Pukurango
Tel: 56-9837
Cable: HEWPAK, Auckland

PAKISTAN
Mushko & Company, Ltd.
Oosman Chambers
Abdullah Heroon Road
Karachi 3
Tel: 511027, 512627
Cable: COOPERATOR Karachi

Mushko & Company, Ltd.
38B, Satalite Town
Rawalpindi
Tel: 41824
Cable: FEMUS Rawalpindi

PHILIPPINES
Electromax Inc.
5th Floor, Architects
Center Bldg.
Ayala Ave., Makati, Rizal
C.C.P.O. Box 1028
Makati, Rizal
Tel: 86-18-87, 87-76-77
Cable: ELEMEX Manila

SINGAPORE
Mechanical and Combustion
Engineering Company Ltd.
8, Jalen Kilang
Red Hill Industrial Estate
Singapore, 3
Tel: 642361-3; 632611
Cable: MECOMB Singapore

Hawlett-Packard Far East
Area Office
P.O. Box 87
Alexandra Post Office
Singapore 3
Tel: 833022
Cable: HEWPAK SINGAPORE

SOUTH AFRICA
Hawlett Packard South Africa
(Pty.) Ltd.
P.O. Box 31718
Braamfontein Transvaal
Minterton
30 Oa Bear Street
Johannesburg
Tel: 725-2080, 725-2030
Talex: 0228 JH
Cable: HEWPAK Johannesburg

Hawlett Packard South Africa
(Pty.) Ltd.
Brescetta House
Bree Street
Cape Town
Tel: 3-6019, 3-6545
Cable: HEWPAK Cape Town
Talex: 5-0006

Hawlett Packard South Africa
(Pty.) Ltd.
641 Ridge Road, Durban
P.O. Box 99
Overport, Natal
Tel: 68-8102
Talex: 567954
Cable: HEWPAK

TAIWAN
Hewlett Packard Taiwan
39 Chung Shiao West Road
Sac. 1
Overseas Insurance
Corp. Bldg. 7th Floor
Taipei
Tel: 389180, 1, 2, 375121,
Ext. 240-249
Talex: TP624 HEWPAK
Cable: HEWPAK Taipei

THAILAND
UHIMESA Co., Ltd.
Chongkolnee Building
56 Suriwongse Road
Bangkok
Tel: 37856, 31300, 31307,
37540
Cable: UHIMESA Bangkok

UGANDA
Uganda Tele-Electric Co., Ltd.
P.O. Box 4449
Kampala
Tel: 57279
Cable: COMCO Kampala

VIETNAM
Peninaur Trading Inc.
P.O. Box H-3
216 Hien-Vuong
Saigon
Tel: 20-605, 63396
Cable: PENTRA, SAIGON 242

ZAMBIA
R. J. Tilbury (Zambia) Ltd.
P.O. Box 2792
Lusaka
Zambia, Central Africa
Tel: 73783
Cable: ARJAYTEE, Lusaka

MEDITERRANEAN AND MIDDLE EAST COUNTRIES NOT SHOWN PLEASE CONTACT:
Hawlett-Packard
Co-ordination Office for
Mediterranean and Middle
East Operations
Via Morocco, 7
I-00144 Rome-Eur, Italy
Tel: (6) 59 40 29
Cable: HEWPAKIT Rome
Talex: B1514

OTHER AREAS NOT LISTED, CONTACT:
Hawlett-Packard
INTERCONTINENTAL
3200 Hillview Ave.
Palo Alto, California 94304
Tel: (415) 326-7000
(Fax: 71 493-1501)
TWX: 810-373-1267
Cable: HEWPAK Palo Alto
Talex: 034-6300, 034-8493

CERTIFICATION

The Hewlett-Packard Company certifies that this instrument was thoroughly tested and inspected and found to meet its published specifications when it was shipped from the factory. The Hewlett-Packard Company further certifies that its calibration measurements are traceable to the U.S. National Bureau of Standards to the extent allowed by the Bureau's calibration facility.



MANUAL PART NO. 12924-90001
MICROFICHE PART NO. 12924-90005

PRINTED IN U.S.A.